



Steps to Change a Side View Mirror

1. **Disconnect the negative battery cable.**
2. **Remove the inner garnish or sail panel** on top corner covering mirror base from inside the vehicle.
3. **Remove the door trim panel** (if necessary). This may require a slight turn to get it loose.
4. For power mirrors **disconnect the power outer connector/plug**. Skip step if installing a manual mirror
5. **Remove bolts or screws** to detach mirror from the door frame.
6. **Grasp the housing and pull the mirror out**. This step may require a little wiggling to get it loose.
7. **Reinstall in reverse order.**
8. Reconnect battery cable and pat yourself on the back!

